


CoroBore® 825 XL/CoroBore® 826 XL



Brücke	1	2 ¹⁾	3	4	5 ¹⁾
Brückengröße M, N und O	Schraube	Schlüssel (mm)	Washer	Schraube	Schlüssel (mm)
	3212 010-569	3021 010-140 (14)	3411 012-170	3212 010-462	3021 010-080 (8.0)

6	7	8 ¹⁾	9 ¹⁾	10	11 ¹⁾
---	---	-----------------	-----------------	----	------------------

Tellerfeder	Parallelstiftsatz	Anschlagplattensatz	Schlüssel (mm)	Schraube	Schlüssel (mm)
3846 010-069	5552 047-01	5335 001-01	3021 010-050 (5.0)	3214 010-355	3021 010-030 (3.0)

Brücke	2 ¹⁾	3	12	13	14 ¹⁾
Brückengröße P, Q und R	Schlüssel (mm)	Washer	Schraube	Schraube	Schlüssel
	3021 010-140 (14.0)	3411 012-170	3212 010-572	3212 010-518	3021 010-100 (10.0)

15	16	17 ¹⁾	18	19	20
----	----	------------------	----	----	----

Scheibe	Schraube	Schlüssel	Parallelstiftsatz	Mitnehmer	Schraube
3411 012-130	3214 010-406	3021 010-040 (4.0)	5552 047-02	3193 110-050	3212 010-511

Brückenverlängerung	4	5 ¹⁾	6	8 ¹⁾	9 ¹⁾
A35-RXLS24-A 060	Schraube	Schlüssel (mm)	Tellerfeder	Anschlagplattensatz	Schlüssel (mm)
	3212 010-462	3021 010-080 (8.0)	3846 010-069	5335 001-01	3021 010-050 (5.0)

Schneidenträger	29	30 ¹⁾	Schieberkörper	21	22 ¹⁾
	Schraube für	Schlüssel (Torx Plus)		Schraube	Schlüssel (mm)
R825C TC..1103, TC..1102, TP..11	5513 020-03	5680 046-03 (7IP)	S24-R820XLS12-012	3214 020-368	265.2-817 (3.0)
R825C CC..09T3	5513 020-09	5680 046-02 (15IP)			

Feinbohrköpfe	9 ¹⁾	23	24	25 ¹⁾	26	27	28
---------------	-----------------	----	----	------------------	----	----	----

A34-R825C...		Schraube für	Spannschraube	Schlüssel (mm)	Schraube	Scheibe	O-Ring
A34-R826C...	Schlüssel (mm)	Einbauhalter					
	3021 010-050 (5)	5513 010-08	5519 026-10	265.2-021 (4.0)	3212 010-360	3411 010-064	3671 010-016

8. Anschlagplattensatz ¹⁾	9 ¹⁾	31	32
	Schlüssel (mm)	Schraube	Scheibe
5335 001-01	3021 010-050 (5)	3212 010-359	3411 011-064

¹⁾ Zubehör ist gesondert zu bestellen.