


## Ersatzteile für CoroMill® 390

## Plan- und Eckfräser



Fräser			1	2			
Größe	$D_c$ mm	$D_c$ Zoll	Schraube	Schlüssel (Torx Plus)	Drehmoment Nm/Zoll, lbs	Molykote	Drehmoment-schlüssel <sup>1)</sup>
11	12-22	.500-.750	5513 020-36	5680 046-01 (8IP)	1.2 /10.6	5683 010-01	5680 100-03
	25-80	1.000-3.000	5513 020-35	5680 046-01 (8IP)	1.2 /10.6	5683 010-01	5680 100-03
17	25	1.000	5513 020-37	5680 046-02 (15IP)	3.0/26	5683 010-01	5680 100-06
	32-125	1.250-5.000	5513 020-39	5680 048-01 (15IP)	3.0/26	5683 010-01	5680 100-06
18	40-200	2.000-8.000	5513 020-29	5680 046-02 (15IP)	3.0/26	5683 010-01	5680 100-06

<sup>1)</sup> Zubehör ist gesondert zu bestellen

Fräsen

E

Bohren

F

Aufbohren

G

Werkzeugsysteme

J

Allgemeine Informationen



D312



D305



D334



D2